## FS10 Quick Start

- 1. Mount the FS10 panel in a suitable location.
- 2. Connect detectors if applicable.
- 3. Connect external activation switches if applicable.
- 4. Connect cables for aerosols and test devices in place of aerosols.
- 5. Connect 2 independent power supplies. Note that they must have same 0V potential. Check if in doubt!
- 6. Go to jke-solutions.dk/fs10/setup/ to configure the panel and finalize the installation.
- 7. Test installation
  - a. Test that all external activation switches are working.
  - b. Test that all detectors are working.
  - c. Test warnings devices are working.
  - d. Activate system and check that all test devices indicate activation.
- 8. Switch off power.
- 9. Disconnect test devices and connect aerosols.
- 10. Turn on power and check "System OK" indicator is lit.





